

Cat.6A/Class EA Modular Plug AWG24-22/1, AWG26/7

<p>1</p> <p>(option)</p> <p>For AWG 26 (OD 5mm-6mm)</p> <p>Suited for AWG 22-26</p>	<p>2</p> <p>AWG 26 (if necessary)</p> <p>Step1 min. 25mm</p> <p>Step2 Stripping length</p> <p>Step3 Fold braid shield backwards</p> <p>Step4 Wrap braid shield evenly around cable jacket</p>	<p>3</p> <p>T568B</p> <p>min. 5mm</p>	<p>4</p>	<p>5</p>
<p>6</p> <p>click</p>	<p>7</p> <p>AWG 26 (if necessary)</p> <p>Braid and shield plate should be wrapped in the cable sealing when OD 5mm-6mm</p> <p>Remove the protective cover</p>	<p>8</p> <p>Slide cable forward until snap-in</p> <p>Lock</p> <p>Press cap to Lock</p>	<p>9</p> <p>1. Shield plate should be wrapped in the SR when OD>6mm</p> <p>OD > 6mm</p> <p>2. Insert SR into the gap</p> <p>3. Tighten cable gland until stop</p> <p>OD 5mm-6mm</p>	<p>10</p> <p>Complete termination</p>

For retermination: Dismounting

<p>1</p> <p>Unlock</p>	<p>Face the latch downward</p> <p>Unlock</p>	<p>2</p> <p>Unlock</p>	<p>Unlock</p>	<p>3</p> <p>Unlock</p>
-------------------------------	--	-------------------------------	---------------	-------------------------------

